



GENERAL INFORMATION

1	THESE PLANS ARE FOR A SIMPLE "PUSH" OR "DOWN HILL" KART. IT IS THE SIMPLEST MOST BASIC KART TO BUILD. DIY TOOLS, E.G.:HAND SAW, HAMMER, NAILS, ELECTRIC DRILL ARE ALL THAT IS REQUIRED.
2	WARNING - THERE ARE NO BRAKES. BRAKES CAN BE USED OF A BYCYCLE IF REQUIRED.
3	PINE (RED DEAL) IS USED THROUGHOUT. STANDARD SIZES/SECTIONS OF TIMER ARE USED. E.G.: 4"X3", 4"X1", 4"X0.5"
4	STEERING IS DONE BY THE DRIVERS FEET - IN PIVOTING THE FRONT AXLE. IT IS POSSIBLE TO USE SOME ROPE TO STEER, AND TO USE FOOTRESTS INSTEAD.
5	SPOKED WHEELS OFF A SMALL BYCYCLE CAN BE USED. THEY ARE HELD IN PLACE USING WASHERS AND SPLIT PINS, WHILE BEEN ABLE TO ROTATE FREELY.
6	ALL DIMENSIONS ARE IN MILLIMETERS (mm).
7	THE AUTHOR/DESIGNER ACCEPTS NO RESPONSIBILITY FOR ANY INJURY CAUSED FROM USING OR DRIVING THIS WOODEN PUSH KART

UNLESS OTHERWISE SPECIFIED
DIMENSIONS ARE IN MILLIMETERS
DO NOT MANUALLY UPDATE
TOLERANCES ARE:
XXX (0 PLS) ±0.5MM
XX.X (1 PLS) ±0.1MM
X.XX (2 PLS) ±0.03MM
UNLESS OTHERWISE NOTED

CAD GENERATED DRAWING
DO NOT MANUALLY UPDATE

APPROVALS

DESIGNER: STEPHEN BURKE

APPROVED:

DATE: 02/02/2007

MATERIAL

FINISH: BREAK ALL SHARP EDGES
R0.13 MAX

DO NOT SCALE DRAWING



WWW.KARTBUILDING.NET

TITLE:
WOODEN PUSH KART

FILE NAME:
Main_Wooden_Kart

DIRECTORY:
C:\Documents and Settings\Administrator\Desktop\Wooden_Kart\

SIZE DWG. NO. :1 REV. 1

SCALE:1:7.5 SIGNATURE: SHEET 1 OF 7

PROPRIETARY AND CONFIDENTIAL
THE INFORMATION CONTAINED IN THIS
DRAWING IS THE SOLE PROPERTY OF
THE DESIGNER. ANY REPRODUCTION IN
PART OR AS A WHOLE WITHOUT THE
WRITTEN PERMISSION OF THE DESIGNER
IS PROHIBITED.