





FIRST: Attach the Bonnet Assembly to the Upper Chassis Assembly  
Nail the Bonnet Assembly to the Upper Chassis & Glue




THIRD: Attach the Brake Lever and bolt in place.

SECOND: Attach the Upper Chassis Assembly to the Lower Chassis Assembly  
Insert the two bolts to secure the Steering Wishbones (front axles).



The Brake Lever is to be made from two 18mm [3/4in] thick pieces of timber nailed and glued together. The top of the Lever is to be rounded and shaped as smoothly as possible. Use a wood chisel, file/rasp and sandpaper to shape.



PROPRIETARY AND CONFIDENTIAL  
THE INFORMATION CONTAINED IN THIS  
DRAWING IS THE SOLE PROPERTY OF THE  
DESIGNER. ANY REPRODUCTION IN PART OR  
AS A WHOLE WITHOUT THE WRITTEN  
PERMISSION OF THE DESIGNER IS PROHIBITED.

kartbuilding.net



TITLE: FINAL ASSEMBLY

MATERIAL AS SPECIFIED

DATE: 26/10/2010

FILE NAME: WOODEN-PUSH-CART

SIZE: A4 REV. 1

SCALE: 1:20 DESIGNER: STEPHEN BURKE

SHEET 10 OF 10

